

## How to find the IP address of your Zip 2x2 handset:

Press the green Fn button, bottom left

Then press Redial/Menu

Press the "Down" arrow key three times to show "Pswd settings"

Press Conf/OK

Press the "Down" arrow once to show "IP settings"

Press Conf/OK

Press the "Down" arrow once again to show "Phone address"

Press Conf/OK

Note down the address

Press Trans/Esc four times to exit



Have you watched our Zultys Tutorials ?

<http://www.brisnorth.com.au/zultys-tutorials/>